
## Installation guide Ely 860 x 340 mm


## Please read the instructions in full before starting to fit your radiator.

- Please check that all parts listed are present before starting installation.
- Valves are not provided, please make sure that you have them before you start. This product requires standard 1/2" radiator valves.
- Before drilling holes for the brackets please check that there are no hidden wires or pipes.
- The plugs supplied are for hard walls masonry only. Please make sure you are using the correct plug for your wall.
- Terma radiators are designed for closed heating systems.
- The radiator should be fitted at least 100 mm from the floor to maximise heat efficiency.
- Noting the distances between bracket centres, mark out the position of the brackets on the wall.
- Drill holes to approximately 80 mm depth using a 10 mm drill bit and insert rawl plugs (1).
- Fasten up wall fixing screws (2) with washers leaving a 3 mm gap between the washer and the wall.
- Hang the radiator on the wall fixing screws (2) making sure each washer is placed between the head of the screw and the fixing bracket. Then fix the screws.
- Connect the water flow using appropriate 1/2" BSP valves. Follow valves manufacture guidelines for correct installation.
- Fill the radiator and purge any trapped air via the bleed valve at the top of the radiator.
- Wipe your radiator down using a clean damp cloth. Never use scourers or abrasives.



## Fixing kit content









For all installation and warranty enquiries please contact Crimson Bear Customer Support on 01535 636256

<sup>\*</sup>Refers to water and dual fuel version

## Mounting bracket TERMA K3; 30 mm; 4x



